

FIG. 2 STORE BASE CONFIGURATION OF TEST 22~ COMPUTER ON PORTABLE BOOT DRIVE (PBD) 23 ~ TRANSFER PBD TO MASTER COMPUTER **IMAGE BASE CONFIGURATION** 24 -TO MASTER IMAGE MEMORY TRANSFER PBD WITH BASE 25 -**CONFIGURATION TO TEST COMPUTER RUN TESTS ON TEST COMPUTER** 26 -IMAGE PBD FROM MASTER IMAGE MEMORY 27~ TRANSFER PBD TO TEST COMPUTER 28 -**BOOT TEST COMPUTER WITH BASE** 29 **CONFIGURATION ON PBD**